

Doorbell intercom quick check set up.

- Fully power doorbell with lead, ensure there is plenty of power in the battery.
- Reset the doorbell but using the small push pin provided, the reset port is in the bottom to the right of the charging port. Hold the pin in to push the button for approximately 5 seconds until you hear a chime.
- Load the app by scanning the Qr code on the instructions or search for Smart home in Google play or apple store. The app is free to download and use, see the icon in the instructions to ensure you load the correct app.
- Connect your phone to your Wi-Fi, must be 2.4 Ghz Wi-Fi files not 5.2 GHz.
- Open the app and create a log in, use an email you have access to, for the registration code.
- Once registered, click add new device. Scroll down the options in the list to get ready to pair the doorbell option.
- Press the doorbell button on the device for 3 seconds the led flashes red. The doorbell is now in paring mode.
- Click the app icon to begin the paring proses and follow the instructions, the visual proses is shown during the paring proses.
- If the pairing fails please reset the device as instructed above and try again, if you have any issues paring the doorbell, then restart your phone and check your Wi-Fi settings to ensure Wi-Fi access is valid and available to the doorbell and your phone.
- Once your app is paired with your doorbell, you can pair the external bell. Click in the app for the bell paring option. See if the bell is paired already, if not, press the small reset button on the bell chimer, at the back, blue led flashes and its ready to pair. Press the doorbell button and the bell chimer should pair. Ensure the bell chimer is selected in the app. You might have to do this once or twice to get the paring done; once it's done you won't have to do it again.